



INSTALLATION INSTRUCTION IN 8 EASY STEPS!


THESE INSTRUCTIONS CAN BE USED TO MOUNT A STICKER ON THE FLOOR, WALL, WINDOW GLASS ETC.




Clean the surface where the sticker is to be mounted. Feel free to use a detergent with alcohol in it to make the surface completely grease-free. The cleaner the surface, the better the sticker will stick.



Plan where the sticker will be located. Use masking tape to attach it to the surface and measure using a ruler or tape measure so that it sits straight. When the sticker is positioned correctly, a piece of tape is inserted over the center to lock it in place.



Remove the tape pieces from one side of the sticker, and then lay it over the taped side of the sticker. Separate the baking paper from the sticker and cut or cut off the baking paper as straight as possible.




Fold back the sticker (**without laying it against the surface**) and start scraping **against the surface** and start scraping from the middle of the tape and out. Scrape in a zigzag pattern where you overlap previous scraping to minimize the risk of air bubbles occurring.



Remove any extra tape from the sticker, and then lay the sticker against the mounted side. Separate the baking paper from the sticker and remove the remaining baking paper.



Fold back the sticker (**without laying it against the surface**) and scrape as in step 4. Any air bubbles can be gently scraped out or by using a needle to make a small hole in the bubble and push out the air.



Carefully pull off the protective and mounting film of the sticker. Pay attention so no parts of the sticker are included. If this is the case, fold back the mounting film slightly and scrape extra on this part.



Use a cloth to gently clean the decal from fingerprints or other dirt.


INSTALLATION INSTRUCTION IN 7 EASY STEPS!

THESE INSTRUCTIONS CAN BE USED TO MOUNT A STICKER ON THE FLOOR, WALL, WINDOW GLASS ETC.




Tools & accessories that are good to have.


- Cleaning Cloth
- Paper tape
- Scissors / Knife
- Scrape
- Measuring tape / Ruler




1 Clean the surface where the sticker is to be mounted. Feel free to use a detergent with alcohol in it to make the surface completely grease-free. The cleaner the surface, the better the sticker will stick.




2 Plan where the sticker will be located. Use masking tape to attach it to the surface and measure using a ruler or tape measure so that it sits straight. When the sticker is positioned correctly, a piece of tape is inserted over the center to lock it in place.




3 Remove the tape pieces from one side of the sticker, and then lay it over the taped side of the sticker. Separate the baking paper from the sticker and cut or cut off the baking paper as straight as possible.




4 Fold back the sticker (**without laying it against the surface**) and start scraping from the middle of the tape and out. Scrape in a zigzag pattern where you overlap previous scraping to minimize the risk of air bubbles occurring.



5 Remove any extra tape from the sticker, and then lay the sticker against the mounted side. Separate the baking paper from the sticker and remove the remaining baking paper.



6 Fold back the sticker (**without laying it against the surface**) and scrape as in step 4. Any air bubbles can be gently scraped out or by using a needle to make a small hole in the bubble and push out the air.



7 Use a cloth to gently clean the decal from fingerprints or other dirt.